

Load cells SAUTER CP P2 · CP P7 · CP P9









CP P2

Single-point load cells of aluminium

CP P7

Single-point load cells of stainless steel

CP P9

Single-point load cells of stainless steel









STANDARD















- Accuracy in accordance with OIML R60 C3
- · RoHS compliant
- Dust and spray protection to IP65 (in accordance with EN 60529)
- · Aluminium, anodised
- · Suitable for price-computing scales, bench scales, etc.
- Maximum platform size 100-300 kg: 400×400 mm
- Maximum platform size 400-500 kg: 450×450 mm
- · Nominal sensitivity: 2 mV/V
- · Note: Version in accordance with OIML R60 C4 or C5 on request

- Accuracy in accordance with OIML R60 C3
- · RoHS compliant
- Dust and spray protection to IP67 (in accordance with EN 60529)
- · Stainless steel
- · Application example: Weight as well as compressive force measurements under harsh environmental conditions
- Suitable for bench scales, price-computing
- Maximum platform size 400×400 mm
- 6-wire connection
- · Nominal sensitivity: 2 mV/V
- · Note: Version in accordance with OIML R60 C4 on request

- Accuracy in accordance with OIML R60 C3
- · RoHS compliant
- Dust and spray protection to IP68/IP69K (in accordance with EN 60529 resp. ISO 20653), welded to create a hermetic seal
- · Stainless steel
- · Area of application: Weight measurement as well as compressive force in harsh environments
- · Suitable for platform scales, checkweighers
- Maximum platform size 10-50 kg: 400×400 mm
- · Maximum platform size 100-500 kg: 800×800 mm
- 4-wire connection (10-50 kg)
- 6-wire connection (100-500 kg)
- · Nominal sensitivity: 2 mV/V
- · Note: Version in accordance with OIML R60 C4 or C5 on request

Model	Nominal load	
SAUTER	kg	
CP 100-3P2	100	
CP 150-3P2	150	
CP 200-3P2	200	
CP 300-3P2	300	
CP 400-3P2	400	
CP 500-3P2	500	

Model	Nominal load	
SAUTER	kg	
CP 30-3P7	30	
CP 50-3P7	50	
CP 75-3P7	75	
CP 100-3P7	100	
CP 150-3P7	150	

Model	Nominal load	
SAUTER	kg	
CP 10-3P9	10	
CP 20-3P9	20	
CP 50-3P9	50	
CP 100-3P9	100	
CP 200-3P9	200	
CP 300-3P9	300	
CP 400-3P9	400	
CP 500-3P9	500	

KERN

Pictograms



Internal adjusting:

Quick setting up of the balance's accuracy with internal adjusting weight (motordriven)



Adjusting program CAL:

For quick setting up of the balance's accuracy. External adjusting weight required



Easy Touch:

Suitable for the connection, data transmission and control through PC or tablet.



Memory:

Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.



Alibi memory:

Secure, electronic archiving of weighing results, complying with the 2014/31/EU standard.



Data interface RS-232:

To connect the balance to a printer, PC or network



RS-485 data interface:

To connect the balance to a printer, PC or other peripherals. Suitable for datatransfer over large distances. Network in bus topology is possible



USB data interface:

To connect the balance to a printer, PC or other peripherals



Bluetooth* data interface:

To transfer data from the balance to a printer, PC or other peripherals



WiFi data interface:

To transfer data from the balance to a printer, PC or other peripherals



Control outputs (optocoupler, digital I/O):

To connect relays, signal lamps, valves, etc.



Analogue interface:

to connect a suitable peripheral device for analogue processing of the measurements



Interface for second balance:

For direct connection of a second balance



Network interface:

For connecting the scale to an Ethernet network



KERN Communication Protocol (KCP):

It is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant parameters and functions of the device. KERN devices featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems



GLP/ISO log:

The balance displays serial number, user ID, weight, date and time, regardless of a printer



GLP/ISO log:

With weight, date and time. Only with KERN printers.



Piece counting:

Reference quantities selectable. Display can be switched from piece to weight



Recipe level A:

The weights of the recipe ingredients can be added together and the total weight of the recipe can be printed out



Recipe level B:

Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display



Totalising level A:

The weights of similar items can be added together and the total can be printed out



Percentage determination:

Determining the deviation in % from the target value (100 %)



Weighing units:

Can be switched to e.g. nonmetric units. See balance model. Please refer to KERN's website for more details



Weighing with tolerance range:

(Checkweighing) Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model



Hold function:

(Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average value



Protection against dust and water splashes IPxx:

The type of protection is shown in the pictogram.

*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners.



Suspended weighing:

Load support with hook on the underside of the balance



Battery operation:

Ready for battery operation. The battery type is specified for each device



Rechargeable battery pack:

Rechargeable set



Universal plug-in power supply:

with universal input and optional input socket adapters for A) EU, CH, GB; B) EU, CH, GB, USA; C) EU, CH, GB, USA, AUS



Plug-in power supply:

230V/50Hz in standard version for EU, CH. On request GB, USA or AUS version available



Integrated power supply unit:

Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request



Weighing principle: Strain gauges: Electrical resistor on an elastic deforming body



Weighing principle: Tuning fork:

A resonating body is electromagnetically excited, causing it to oscillate



Weighing principle: Electromagnetic force compensation:

Coil inside a permanent magnet. For the most accurate weighings



Weighing principle: Single cell technology: Advanced version of the force compensation

principle with the highest level of precision



Verification possible:

The time required for verification is specified in the pictogram



DAkkS calibration possible (DKD):

The time required for DAkkS calibration is shown in days in the pictogram



Factory calibration (ISO):

The time required for Factory calibration is shown in days in the pictogram



Package shipment:

The time required for internal shipping preparations is shown in days in the pictogram



Pallet shipment:

The time required for internal shipping preparations is shown in days in the pictogram

KERN - Precision is our business

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAkkS calibration certificate the best pre-requisite for proper

The KERN DAkkS calibration laboratory today is one of the most modern and bestequipped DAkkS calibration laboratories for balances, test weights and force-measure-

Thanks to the high level of automation, we can carry out DAkkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

. . .

- DAkkS calibration of balances with a maximum load of up to 50 t
- DAkkS calibration of weights in the range of 1 mg 2500 kg
- Volume determination and measuring of magnetic susceptibility (magnetic characteristics) for test weights
- Database supported management of checking equipment and reminder service
 Calibration of force-measuring devices
- DAkkS calibration certificates in the following languages DE, EN, FR, IT, ES, NL, PL
- Conformity evaluation and reverification of balances and test weights

Your KERN specialist dealer: